


MODEL: HEH00552
Theft Deterrent Ladder Section

- Always Wear a Safety Harness with this Product
- Practice Using at Ground Level
- Tree Size: 9"-18" diameter

FIELD & STREAM™

**FITS
14 INCH WIDE
LADDERS**



Warning Warning Warning Warning

The enclosed ladder section is only to be used to replace the ladder section for Ladder Stand Model #'s HEH00533, HEH00534, HEH00535, HEH00536, and HEH00537.

USE ONLY ONE SECTION PER TREESTAND

Using additional ladder sections over the designated height other than the heights specified in the user instructions **CAN CAUSE SERIOUS INJURY OR DEATH**

Follow all instructions and warnings before each use detailed in your original assembly instructions.

THANK YOU! for purchasing the Theft Deterrent Ladder Section by Primal Vantage Company Inc.

Warning

Every year serious injury and even death occurs from hunting related falls. To ensure your safety, please **COMPLETELY** read and follow this safety manual and ALL warning labels **BEFORE** assembling, installing or utilizing this product.

DO NOT USE THIS PRODUCT BEFORE FULLY UNDERSTANDING ALL SAFETY WARNINGS AND INSTRUCTIONS. IF YOU HAVE QUESTIONS, ARE UNSURE ABOUT ANY INFORMATION OR NEED ADDITIONAL INFORMATION CONCERNING YOUR PRODUCT, CONTACT OUR CUSTOMER SERVICE DEPARTMENT AT 1-866-972-6168 OR VISIT WWW.TREESTANDCUSTOMERSERVICE.COM. KEEP AND MAINTAIN THIS SAFETY AND INSTRUCTION MANUAL IN A SAFE LOCATION FOR FUTURE REFERENCE.

TREESTAND SAFETY WARNINGS

Please read the following instruction manual and warnings labels completely before utilizing this tree stand. Failure to understand and execute the instructions and warnings may result in serious injury or death. In the event of an accident, have a plan for rescue, including the use of devices that may be easily reached while suspended. **NEVER** hunt without a rescue plan.

ALWAYS read all warnings and instructions before each use of this tree stand. Failure to read all warnings and instructions may result in serious injury or death.

ALWAYS wear a Full Body Safety Harness after leaving the ground. Failure to wear your Fall Arrest System (Harness) may result in serious injury or death.

ALWAYS use a Full Body Safety Harness when using this tree stand. This tree stand includes a TMA Certified Full Body Harness. The TMA Certified Full Body Harness must always be connected to yourself and the tree during ascending, hunting and descending. Single safety belts and chest harnesses are no longer allowed and should **NEVER** be used. If you are not wearing a full body harness properly attached to the tree that is protecting you from a fall, **DO NOT** leave the ground. Falls can occur at anytime after leaving the ground.

ALWAYS inspect the tree stand and the **Fall Arrest System** (Harness) for signs of wear or damage **BEFORE** each use. Also inspect to ensure that nuts and bolts are secure. Pay special attention to the harness and straps, guaranteeing that nothing has been frayed or severed. Destroy all products that cannot be repaired by the manufacturer. Contact a Customer Service Representative for replacement parts. The Fall Arrest System **MUST** be discarded and replaced after a fall has occurred.

DO NOT use tree stand if any nuts or bolts or parts are loose, bent, or crooked.

NEVER exceed total weight limit of **300 lbs.** **DO NOT** use if your combined weight with all of your hunting gear and any accessories exceeds **300 lbs.** Use of tree stand over the weight limit may result in serious injury or death.

NEVER let children play with or use this tree stand without adult supervision. This tree stand is not a toy.

DO NOT use this tree stand while under the influence of alcohol, medication or any illegal substances. Use of tree stand while under the influence of any of these substances may result in serious injury or death.

NEVER use this tree stand during inclement weather. **DO NOT** use tree stand during thunderstorms, snowstorms, hurricanes, tornadoes or any other weather conditions that include (but not limited to) lightning, icy conditions, or high winds that could create slippery or dangerous situations. End your hunt and return to the ground if inclement weather conditions arise.

NEVER use this tree stand if you have a history of health problems such as (but not limited to) heart problems, back problems, high blood pressure, impaired vision, equilibrium impairments, are afraid of heights, have been advised by a doctor or physician not to climb. If you are not physically fit, well rested, and alert, or if you have any other physical or mental condition that would impair your ability to properly use this tree stand.

NEVER use tree stand if you are feeling ill, nauseous, dizzy or if you have prior medical conditions that could cause a problem i.e., heart condition, joints that lock-up, spinal fusions, etc. or if you are not well rested and alert. Physical ailments can reduce your ability to safely install, utilize, and remove your tree stand. Please consult a physician prior to use.

NEVER wear jewelry or loose fitting clothing, which can cause hazardous conditions. Clothing may be caught in your equipment and cause you to fall. You must always wear non-slip or rubber boots. Shoelaces must be tucked into your boots. Rings and necklaces **MUST NOT** be worn.

NEVER use this tree stand on a tree that is dead, leaning, diseased, loose barked or on a utility pole as the tree may fall, break, or uproot and may result in serious injury or death.

NEVER transport any of your equipment with yourself while ascending or descending the tree. You will need to have two hands free during ascending and descending for safety. Use a haul line to pull up your firearm (unloaded, chamber opened with safety lock engaged, barrel facing towards the ground), bows, arrows, knives or any other equipment to your tree stand once you have reached your desired hunting height. **ONLY** pull up hunting equipment after the tree stand has been secured to the tree and after you and your harness have been secured to the tree. Prior to descending, lower your equipment on the opposite side of the tree from which you are climbing. Make sure that the unloaded firearm's safety lock is engaged and the gun barrel is pointing towards the ground.

ALWAYS hunt with a plan and a buddy. Before you leave home, let others know your exact location, when you plan to return and who is with you.

ALWAYS inform someone of the hunting location, where the treestand is located and the expected duration of the hunt.

ALWAYS attach your Full Body Harness in the manner and method described by the manufacturer. Beware of hazards associated with Full Body Harnesses and the fact that prolonged suspension in a harness may be fatal. Have in place a plan for rescue, including the use of cell phones, or signal devices that may be easily reached while suspended. If rescue personnel cannot be notified, you must have a plan for recover/escape. If you have to hang suspended for a period of time before help arrives, exercise your legs by pushing against the tree or doing any other form of continuous motion. Failure to recover in a timely manner could result in serious injury or death. If you do not have the ability to recover/escape, hunt from the ground.

ALWAYS carry emergency signal devices such as a cell phone, walkie-talkie, whistle, signal flare, PLD (personal location device) and flashlight with you at all times and within reach even while you are suspended in your harness. Watch for changing weather conditions. In the event of an accident, remain calm and seek help immediately.

NEVER modify or alter your tree stand in anyway by making repairs, replacing parts, or altering, adding or attaching anything to it except if explicitly authorized by the manufacturer. Improper installation or adjustment may cause serious injury or death. Remove all contents from box. Inspect for any damaged or missing parts. If any parts are missing or damaged, you must only use certified replacement parts. Using any other replacement parts will void product warranty. **THERE ARE NO EXTRA PARTS.** All parts **MUST** be used to ensure the safety of you and your stand. If you think parts are missing or damaged, **STOP IMMEDIATELY** and contact our Customer Service Department. Using the tree stand with missing or damaged parts may result in serious injury or death. Contact a Customer Service Representative if you have any missing, damaged or extra parts.

TREESTAND SAFETY WARNINGS

PRACTICE installing, adjusting and using your tree stand at ground level prior to using it at an elevated position.

ALWAYS step firmly on the first rung of the bottom ladder section to set the ladder into the ground before proceeding to climb the ladder.

NEVER use homemade or permanently elevated stands or make modifications to a purchased tree stand.

ALWAYS have a minimum of three people present when installing or removing this tree stand.

ALWAYS know your physical limitations. Don't take chances. If you start thinking about how high you are, don't go any higher. Instead, choose a minimum height that will allow for safe, effective and comfortable hunting.

NEVER use this tree stand for any use other than hunting. Our tree stands are designed for hunters to wear a Full Body Harness. If you are not completely comfortable and confident with your ability to safely install, ascend, hunt and descend using this treestand and a Full Body Safety Harness, **DO NOT PROCEED.**

ALWAYS lean **forward towards the tree** as you climb and attach your harness to the tree before securing the platform to the tree and stepping onto the platform.

NEVER lean out from the tree stand for any reason.

NEVER use this treestand for trimming trees.

NEVER rely on a branch for support.

NEVER jump or bounce on the tree stand's platforms or ladder sections to seat it to the tree.

NEVER fall asleep in your tree stand as you may fall out resulting in serious injury or death.

NEVER adjust your tree stand while in use. **ALWAYS** ensure that you and your tree stand are safely secured to a healthy tree. Your tree stand **MUST** be attached tightly to the tree and secured in place. If the stand is not secure, it may shift while in use, resulting in serious injury or death.

ALWAYS maintain three points of contact when climbing the tree stand. (Two feet, one hand **or** one foot, two hands)

Instructions should be kept in a safe place and reviewed before each use. It is the responsibility of the treestand owner to furnish the complete instructions to anyone who borrows or purchases the tree stand from you.

ALWAYS be sure to retighten all bolts **BEFORE** each new use of tree stand.

DO NOT leave your tree stand outside. It must be stored inside when not in use.

The Installation Cross Straps and Stabilizer Bar **MUST** be properly installed before each use of treestand.

ALWAYS inspect every ladder section connection every time you use the tree stand before leaving the ground. If the ladder sections are separating, with the help of three other people remove the tree stand from the tree and reinstall.

ALWAYS check the ground under the tree stand to make sure it is firm and level. Sloping ground or uneven surfaces (one side of a rock or root) can cause your tree stand to tilt or shift off the tree.

ALWAYS read and understand all warnings and instructions before each use of tree stand. Failure to read and understand all warnings and instructions may result in serious injury or death.

NEVER use this tree stand with a second person. The product is designed for use by **ONE** person **ONLY.**

Read and understand manufacturer's warnings, expiration date (if applicable) and instructions on how to properly adjust the harness.

PRACTICE using the Full Body Safety Harness at ground level in the presence of a responsible adult to experience the feeling of hanging suspended before using in a hunting environment.

There is time to make a correct decision on what action to take if a fall occurs while wearing a Full Body Harness. It is important to remember do not panic. Remain calm and implement your practiced rescue, relief and recovery plan.

! WARNING

DO NOT use this ladderstand without reading and following all warnings and instructions before each use. Failure to do so may result in serious injury or death.

ALWAYS inspect your ladderstand before each use. **DO NOT** use if parts are missing, worn, or damaged.

ALWAYS wear a Full Body Harness while using this ladderstand. Failure to wear a full body harness while using this ladderstand may result in serious injury or death.

DO NOT exceed the ladderstand's 300 lbs. weight which includes your body weight as well as the weight of your clothes and gear. Exceeding the ladderstand's weight limit may cause the treestand to break or fail resulting in serious injury or death.

NEVER stand on treestand seat or arms. Lifting or dropping of these parts may cause the treestand to break or fail resulting in serious injury or death.

NEVER alter, modify, or damage the ladderstand. **NEVER** use on wet, uneven, or sloping ground. The tree may fall, break, or root may be exposed resulting in serious injury or death.

NEVER use ladderstand if you have dizzy spells, a heart problem, are afraid of heights, have been advised by a doctor or other health care provider not to climb, or have any condition that would impair your ability to climb up or down or use treestand as it could result in serious injury or death.

NEVER use ladderstand during inclement weather. **DO NOT** use treestand during thunderstorms or any other weather conditions including (but not limited to) lightning, freezing rain, high wind that could create slippery or dangerous conditions.

DO NOT use ladderstand under the influence of alcohol, drugs, or medication. Using ladderstand under the influence of alcohol, drugs, or medication may result in serious injury or death.

NEVER use ladderstand if you have dizzy spells, a heart problem, are afraid of heights, have been advised by a doctor or other health care provider not to climb, or have any condition that would impair your ability to climb up or down or use treestand as it could result in serious injury or death.

NEVER remove or deface ladderstand warning labels. Replacement labels can be obtained from the address below.








NEVER remove any safety warning stickers from this product.

Safety must be your first priority during the use of this product.

MODEL: HEH00552
Theft Deterrent Ladder Section

- Always Wear a Safety Harness with this Product
- Practice Using at Ground Level
- Tree Size: 9"-18" diameter

FIELD & STREAM™



Parts List

A	1 Ladder Section	Part # DL-552
B	1 Removable Rung	Part # DRR-552
C	4 Installation Knob	Part # IK-100
D	1 Stabilizer Bar	Part # DSB-100
E	1 Adjustment Knob	Part # AK-100
F	2 Sleeve	Part # DS-100
G	1 Buckle Strap Assy	Part # DBA-200
H	2 M10 Quickclip	Part # 1015
45	1 M12x45mm Bolt w/wingnut	Part # 1245W

⚠ Warning ⚠ Warning ⚠ Warning ⚠


The enclosed ladder section is only to be used to extend the ladder section for Ladder Stand **Model #'s HEH00533, HEH00534, HEH00535, HEH00536, and HEH00537.**

USE ONLY ONE SECTION PER TREESTAND



Using additional ladder sections over the designated height other than the heights specified in the user instructions **CAN CAUSE SERIOUS INJURY OR DEATH**

Follow all instructions and warnings before each use detailed in your original assembly instructions.

You MUST lower the stand to the ground before assembling the Ladder Section to your stand.
You MUST have the help of at least two other people



1. Insert Removable Rung **B** into the space on Ladder Section **A**.




2. Thread each Installation Knob **C** through the ladder section and into the threaded holes of the Removable Rung **B**.

⚠ WARNING ⚠


DO NOT use Ladder Section without the Removable Rung installed. Using the Ladder Section without the Removable Rung installed may result in serious injury or death.

You **MUST** lower the stand to the ground before assembling the Ladder Section to your stand. You **MUST** have the help of at least two other people


3. With the help of at least two other people, lower your Comfort Zone or Field & Stream treestand to the ground. Disassemble the ladder sections from each other.




4. Slide Sleeves **F** over the crimps of Ladder Section **A**.




5. Insert Ladder Section **A** into the Original Middle Ladder Section .



6. Slide the Sleeves over the joint where ladder sections are connected.



7. Insert 1 - **Quickclip** through the hole on the sleeve, and through the ladder sections on each side of the ladder.




8. Close the quickclip to secure the ladder sections together.



9. Slide the inner part of the Stabilizer Bar into the outer part. Attach Stabilizer Bar **D** to the top rung of the Theft Deterrent Ladder Section with **1 - M12x45w bolt and 1 wingnut**.

Insert the Adjustment Knob **E** in the Stabilizer bar at the proper adjustment point to the tree.





11. Attach Buckle Strap **C** just behind the brace of the inner part of Stabilizer Bar **D** by following the Strap Installation below. **(See Photo Inset)**

Position the Stabilizer Bar against the tree and secure it by wrapping the strap around the back of the tree once and insert the strap into the buckle. **(See Buckle Instructions Below)**

10. Refer to the original manufacturer's instructions to raise the stand against the tree.

Strap Installation



Buckle Instructions

