


**MODEL: HEH00518**  
**ROOF KIT**

- Tree Size: 9"-18" diameter

# FIELD & STREAM™



**MODEL: HEH00518**

**THANK YOU!** for purchasing the Field & Stream Roof Kit by Primal Vantage Company Inc.













**⚠ Warning**

**Every year serious injury and even death occurs from hunting related falls.** To ensure your safety, please **COMPLETELY** read and follow this safety manual and ALL warning labels **BEFORE** assembling, installing or utilizing this product.

DO NOT USE THIS PRODUCT BEFORE FULLY UNDERSTANDING ALL SAFETY WARNINGS AND INSTRUCTIONS. IF YOU HAVE QUESTIONS, ARE UNSURE ABOUT ANY INFORMATION OR NEED ADDITIONAL INFORMATION CONCERNING YOUR PRODUCT, CONTACT OUR CUSTOMER SERVICE DEPARTMENT AT 1-800-722-7345 OR VISIT [WWW.TREESTANDCUSTOMERSERVICE.COM](http://WWW.TREESTANDCUSTOMERSERVICE.COM). KEEP AND MAINTAIN THIS SAFETY AND INSTRUCTION MANUAL IN A SAFE LOCATION FOR FUTURE REFERENCE.

# MODEL: HEH00518 Roof Kit


• Tree Size: 9"-18" diameter




## Parts List

<b>A</b>	2 Front Frame Corner	Part # RK-1000
<b>B</b>	2 Rear Frame Corner	Part # RK-1005
<b>C</b>	2 Side Brace	Part # RK-1010
<b>D</b>	1 Left Rail Support Brace	Part # RK-1015
<b>E</b>	1 Right Rail Support Brace	Part # RK-1020
<b>F</b>	1 Front Brace	Part # RK-1025
<b>G</b>	1 TopTree Brace	Part # RK-1030
<b>H</b>	1 Bottom Tree Brace	Part # RK-1035
<b>J</b>	1 Vertical Support	Part # RK-1040
<b>K</b>	1 Fabric Cover	Part # RK-1045
<b>L</b>	3 Pole	Part # RK-1050
<b>M</b>	2 Buckle Strap	Part # RK-1055
<b>N</b>	1 M10 Knob	Part # 1600
<b>40</b>	2 M10x40mm Bolt	Part # 1040
<b>55</b>	2 M12x55mm Bolt	Part # 1255


# FIELD & STREAM™




1. Slide Front Brace **F** onto Front Frame Corner **A**.




2. Slide each Side Brace **C** onto the other end of Front Frame Corner **A**. There are three holes on each side brace that **MUST** be facing the inside of the frame. **SEE CLOSEUP**






3. Slide each Rear Frame Corner **B** into Top Tree Brace **G** .  
The "U" part of the brace **MUST** be on top of the frame.  
**SEE CLOSEUP**




Closeup




4. Slide each Rear Frame Corner **B** into Side Braces **C** .


**NOTE:** ALL WASHERS ARE AGAINST THE BOLT HEAD AND THE NUT UNLESS STATED OTHERWISE

5. Attach Left Frame Support **D** on the Right Side Brace **C** using **1-M10x40mm bolt**. (When you install it on the tree it will be on the left side.)



6. Attach Right Frame Support **E** (the one with the nut on it) on the Left Side Brace **C** using **1-M10x40mm bolt**. (When you install it on the tree it will be on the right side.)







**NOTE:** ALL WASHERS ARE AGAINST THE BOLT HEAD AND THE NUT UNLESS STATED OTHERWISE

7. Attach Vertical Support **J** to Top Tree Brace **G** with **1-M12x55mm bolt**.


8. Attach Bottom Tree Brace **H** to Vertical Post **J** using **1-M12x55mm bolt**.





**NOTE:** ALL WASHERS ARE AGAINST THE BOLT HEAD AND THE NUT UNLESS STATED OTHERWISE


9. Attach Left and Right Frame Supports to Vertical Support **J** using M10 Knob **N**. The Knob will go through Left Frame Support **D** then through Vertical Post **J** then tightened through Right Frame Support **E**. **SEE CLOSEUP**








10. Lay Cover on ground with the black side down and the camo side up.

11. Insert Poles **L** through Cover **K**.






12. Insert top Pole **L** into Front Frame Support **A**.  
Insert middle Pole **L** into Side Brace **C**.  
Insert bottom Pole **L** into Rear Frame Support **B**.



13. Attach Fabric Cover **K** to the assembled frame by using the self sticking fabric strips on the front, rear and sides of the frame.



16. Raise the Roof Assembly to the tree using a safe hoist/lift system to 3 feet above the shooting rail of your treestand.

17. Attach the Vertical Support to the tree by using the two Buckle Straps **M** . Hook one end of the strap to Top Tree Brace **G** , wrap the strap around the tree once and insert the other hook into the other side of the tree brace. Pull strap until it is tight against the tree. Attach the other strap to Bottom Tree Brace **H** , wrap the strap around the tree once and insert the other hook into the other side of the tree brace. Pull strap until it is tight against the tree.

## **⚠ WARNING**

You *MUST* use a Hoist system to lift the Roof to the Stand for installation  
*DO NOT* climb the Ladder with the Roof and Blind in Hand

## **⚠ WARNING**

*NEVER* stand on seat platform to attach roof.  
Raise flip-up seat platform to move closer to tree.

# DETAILED BUCKLE AND STRAP INSTRUCTIONS



Fig. 1

1. Hold buckle as shown in Fig. 1




Fig. 2

2. Press down on latch and insert strap underneath teeth as shown in Fig. 2.



Fig. 3

3. Pull strap to desired length.




Fig. 4

4. Pull slack to tighten.  
(See Fig. 4)